

Surface deterioration caused by chemical de-icers is not a concrete quality problem, but rather a concrete maintenance issue. Proper use and maintenance of finished concrete products are the end-user's responsibility.

De-icers

Achieving a quality long-lasting concrete product is dependent on using good materials, proper construction techniques and protection from adverse conditions. Exterior concrete such as pavements, garage slabs, driveways, aprons, sidewalks and gutters are especially susceptible to adverse environmental conditions when de-icing chemicals are used improperly. The use of de-icing salts containing chlorides may cause spalling and degradation of concrete surfaces. This is especially true with new concrete surfaces and has resulted in a considerable amount of damage to quality concrete within the first winter season.

Once properly placed and cured, the following instructions can minimize spalling and surface degradation caused by the use of de-icing chemicals:

1. Do not use de-icing chemicals containing chloride compounds. This includes, but is not limited to, calcium chloride, magnesium chloride, sodium chloride (salt) and potassium chloride. Never use any deicer that contains either ammonium sulfate or ammonium nitrate.
2. Remove snow and ice manually as it accumulates by shovelling, plowing or other mechanical means.
3. Wash driveways and other concrete surfaces, whenever the weather allows, to remove salts that drip off of vehicles. Many government agencies are using chlorides on roads and bridges for de-icing.
4. Be aware that many chemical fertilizer products can be harmful to concrete surfaces.

- ⦿ **Do not use de-icing chemicals containing chloride compounds, including calcium chloride, magnesium chloride, sodium chloride and potassium chloride. Never use de-icing chemicals that contain either ammonium sulphate or ammonium nitrate. Use sand on ice for safety.**
- ⦿ **Keep concrete free of ice and snow.**
- ⦿ **Ammonium nitrate is found in many fertilizers and these fertilizers should not be allowed to remain on surfaces.**
- ⦿ **Flower pots with soil containing fertilizer will damage the concrete slab they sit on.**
- ⦿ **Avoid using acids to clean concrete.**
- ⦿ **Membrane sealers need to be reapplied at least every other year or when the finish shows signs of wear.**
- ⦿ **Siloxane or silane water repellents should be reapplied every two to three years.**

The information contained in this brochure is, to the best of our knowledge, true and accurate, but all recommendations or suggestions are made without guarantee. The information has been obtained from reliable sources, but Independent Concrete Ltd. cannot guarantee that it is accurate or complete. This brochure is not a complete analysis of every material fact regarding exterior residential concrete flatwork. Since the conditions of your use of our products are beyond our control, Independent Concrete Ltd. disclaims any liability incurred in connection with the use of our products and information contained herein. This information is provided for use by personnel who are competent to evaluate the significance and limitations of the information provided and who will accept total responsibility for the application of this information. No person is authorized to make any statement or recommendation not contained herein, and any such statement or recommendation so made shall not bind the company.



Effort = Concrete Results

Best Practice Concrete Installation And Maintenance Guide Exterior Concrete Slabs



Questions or comments?

Call (250) 478-0555

www.iconcrete.ca

Best Practices - Concrete Installation and Maintenance Guide

Product Design

- ✓ 32 MPa
- ✓ 80mm ± 20mm Slump
- ✓ 0.45 Water/Cement Ratio
- ✓ Air Entrained (6%±1%)
- ✓ Water Reducer
- ✓ Thickness (minimum 100mm)

Placing Concrete

- ✓ Place concrete within 1½ hours of batching.
- ✓ Place concrete at less than a 100mm slump.
- ✓ **Once the load is adjusted to the design slump, additional water should not be added.**

Consolidating and Finishing Concrete

- ✓ Screed or strike off.
- ✓ Level concrete by using a bull float to smooth surface prior to the presence of bleed water.
- ✓ Grooving and edging should be performed immediately after bull-floating before bleed water is present on the surface.
- ✓ Control joints should be a maximum 8'-10' apart.
- ✓ Do not use steel trowels, steel groovers and steel edgers on air-entrained concrete.
- ✓ Bleed water must disappear before any further finishing operations. Finishing bleed water back into the concrete may result in durability problems (delamination and scaling).
- ✓ If evaporation rates are high, use an evaporation retarder (Confilm) between finishing operation to prevent plastic shrinkage cracks. Do not work these products back into the surface.
- ✓ A medium to fine transverse broom texture will provide a uniform nonslip surface.
- ✓ **Never sprinkle or work in water or cement on concrete flatwork while finishing**

Placing and Curing Concrete

Hot Weather

- ✓ Hot weather accelerates setting times requiring more rapid finishing.

- ✓ During sunny, windy, low-humidity weather conditions, the concrete surface can lose moisture rapidly and crack prior to hardening (plastic shrinkage cracks).
- ✓ When weather conditions cause plastic shrinkage cracking, the surface must be kept moist by a fog sprayer or the application of a mono-molecular film (Confilm) to retard the moisture evaporation until curing is applied.
- ✓ The water or film is not to be worked back into the surface, but rests there until it evaporates.
- ✓ Use of synthetic fibres can reduce the formation of plastic shrinkage cracks.

Cold Weather

- ✓ In cold weather, the concrete surface temperature needs to be maintained at 10°C to 30°C for seven days (blankets).
- ✓ To prevent thermal cracking after curing, the temperature of concrete shall be reduced at a rate not to exceed 10°C in 24 hours.
- ✓ In the fall (Oct. 1), use blankets or plastic in place of curing compound. Curing compounds may trap excess water in the slab after the initial cure time and prevent the appropriate drying time.
- ✓ To prevent scaling, concrete needs 30 days of air drying after the curing period before subjecting the new slab to freeze-thaw cycling.
- ✓ Some new studies recommend that a siloxane or silane sealer be applied before subjecting the slab to de-icing salt.

Curing Concrete

- ✓ The curing process should start within 15 minutes of the final finishing operation.
- ✓ Curing can be accomplished by several methods:
 - Use burlene (plastic-backed burlap).
 - Use waterproof paper.
 - Use white plastic.
 - Use (solvent or water base) acrylic cure & seal.
 - Flood the slab with water upon final set.

- ✓ Inform the owner of the value of proper curing.
- ✓ No vehicles on the slab for seven days.
- ✓ **Do not apply de-icers. Use sand.**
- ✓ Curing should continue for seven days.

Drying Concrete Slab

- ✓ To prevent scaling, concrete needs 30 days of air drying after the curing period before subjecting the new slab to de-icing chemicals and freeze-thaw cycle begins.
- ✓ Oct. 1 is a guideline as the latest date for pouring exterior concrete with the best chance of completing the curing, drying and sealing before the first freeze-thaw cycle begins.
- ✓ New studies are recommending that a siloxane or silane sealer be applied before subjecting the slab to de-icing chemicals (apply after 30 days of air drying and before daytime temperature drops below 10 °C).

Protect Concrete - Sealing

- ✓ It is important to prevent newly placed concrete from being saturated with water prior to freeze-thaw cycles during the winter months.
- ✓ We recommend applying solvent base acrylic cure and seal and/or siloxane or silane sealers.
- ✓ Concrete should be reasonably dry prior to the application of the sealer.
- ✓ Follow the manufacturer's recommendations for application procedures and frequency.
- ✓ **Concrete that cannot be sealed should be protected from de-icing chemicals until a sealer can be applied.**

If you are not the owner of the newly installed concrete, forward this pamphlet to the owner and advise them of the precautions necessary to maintain the quality product you installed for them.